

Rancho RS6224 Oil Pan Armor Kit

1. Clean and dry oil pan surface. Apply a 3/8" bead of silicone liberally to the inside of oil pan armor 176560.
2. Allow 15 minutes for silicone to skin-over, then place Rancho armor over oil pan. Using a jack and wooden block, press armor onto the oil pan until fully seated.
3. Support the assembly overnight with a jack stand. The silicone fully cures in 24 hours.

Note: For additional support, secure the armor to the oil pan with wire (not supplied). See illustration below



Rancho RS6224 Oil Pan Armor Kit

1. Clean and dry oil pan surface. Apply a 3/8" bead of silicone liberally to the inside of oil pan armor 176560.
2. Allow 15 minutes for silicone to skin-over, then place Rancho armor over oil pan. Using a jack and wooden block, press armor onto the oil pan until fully seated.
3. Support the assembly overnight with a jack stand. The silicone fully cures in 24 hours.

Note: For additional support, secure the armor to the oil pan with wire (not supplied). See illustration below

